

# SiliGrout 1C

## Grouting and filler material for CorrAnodes

### Application Guide

		
<b>Pilot holes are pre-drilled and anode wire slots are grinded</b>	<b>Holes and slots are cleaned and pre-wetted</b>	<b>CorrAnodes are placed in the pilot holes</b>
		
<b>PS foam caps are cut in form and temporarily glued on the holes</b>	<b>SiliGrout is mixed with water and prepared</b>	<b>SiliGrout is poured in with a water can</b>
		
<b>SiliGrout is cured for at least 4 hrs</b>	<b>PS foam caps are removed</b>	<b>After cured the slots and concrete is smoothed with CorroFix RM</b>

CorrPRE Engineering BV, Zuidbaan 509, 2841MD Moordrecht, Netherlands

**Revision Nr.**  
02

**Revision date**  
25<sup>th</sup> June 2020

**Approved**  
R. Giorgini

All technical data stated in this Technical Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control. The information, and, in particular, the recommendations relating to the application and end-use of CorrPRE's products, are given in good faith based on CorrPRE's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with CorrPRE's recommendations.